

Phone: (888) PEN-KITS

(736-5487)

www.WoodTurningz.com

## **CLEVER CLICK PEN**

## Instructions

## Kit Features

- Click mechanism
- Parker<sup>™</sup> style refills (RE-PARK)
- Overall length: 5-1/2"

## **Required Accessories & Materials**

- 7mm mandrel
- 2-pc. Race Car bushing set (PKRACEBU)
- Drill bit 3/8" (DB3/8)
- Universal trimming kit (BTRIMKIT8)
- Glue (We recommend the thick "gel" CA glue—GTHICK2)
- · Sanding and finishing supplies

# Diagram A - Parts and Assembly 2-15/16" Tube Clip Clicker Assembly NOTE: Do not press against the plunger during assembly. Refill Spring Parker™ Refill

## **BLANK PREPARATION**

The Clever Click pen has a tube measuring 2-15/16". **Cut** your blank approximately 1/16" longer than the tube to allow for squaring with the barrel trimmer. Use a medium drill speed to **drill** the blank. Raise the bit from the blank every 1/4" to 1/2" to allow the chips to clear from the flutes of the drill bit. Don't force the drill bit; use an even pressure and let the bit do the work. After drilling the blank, **sand** the exterior of the brass tube to roughen its surface and use CA **glue** to glue the tube inside the blank. Sand or barrel trim to **square** the ends of the blank.

## **TURNING THE PEN**

**Set up** the mandrel as shown in Diagram C. The Clever Click pen's upper and lower bushings both have an outside diameter of .475" (see Diagram B). **Turn** the pen blank to the bushing diameter at the ends. **Sand** with abrasives and **finish** with your choice of polish.

### **ASSEMBLY**

(Line up finished parts according to Diagram A)

To avoid damage to components when assembling, use a vise with covered jaws or one of WoodTurningz' pen presses.

- 1. Unscrew the plunger at the end of the Clip/Clicker Assembly.
- 2. Place the Clip between the Clicker Assembly and the top of the barrel.
- 3. Press the Clip/Clicker Assembly into the upper end of the barrel.
- 3. Press the Tip onto the lower end of the barrel.
- 4. Screw the plunger back into place onto the Clicker Assembly.
- 5. Remove the front portion of the Tip. Slide the spring onto the refill and place inside the assembled Pen Body.
- 6. Replace threaded Tip.
- 7. The pen is now ready to operate.

## Diagram B - Bushings 0.475" Diagram B - Bushings 0.475" Diagram C - Turning the Pen 7mm spacer bushings Barrel Locknut Live Center

