

Phone: (888) PEN-KITS

www.WoodTurningz.com

MINI BULLET KEYCHAIN KIT

Instructions

DIAGRAM A Keychain Assembly



BLANK PREPARATION

Cut your blank approximately 1/16" longer than the tube to allow for squaring with the barrel trimmer. **NOTE: Any size tube length will work with these kits (as long as it is 7mm) so feel free to swap out a longer length and be creative! Use a medium drill speed to drill the blank. Raise the bit from the wood every 1/4" to 1/2" to allow the chips to clear from the flutes of the drill bit. Don't force the drill bit; use an even pressure and let the bit do the work. After drilling the blank, sand the exterior of the brass tube to roughen its surface and use CA glue to glue the tube inside the blank. Sand or barrel trim to square the ends of the blank.

TURNING THE ORNAMENT

Set up your mandrel as shown in Diagram B. You will use a bushing on each end (PKKEYMB-BU). Turn the blank in a creative shape. (with this kit, tapering to the bushing diameter at the ends is optional). Sand with abrasives and finish with your choice of polish.

ASSEMBLY

(Line up finished parts according to Diagram A)

To avoid damage to components when assembling, use a vise with covered jaws or one of WoodTurningz' pen presses.

1. Press the Cap into the end of the tube and then do the same with the Tip.



Tip



PKKEYMB-BU

.343"

.374" **DIAGRAM B - Turning the Keychain**

