

Instructions:

- Press Tip into barrel before using Jig.
- Place Jig onto press between pressing jaws.
- Slide Tip over post (1) and place Mechanism at open end of Barrel (2).
- Lay Mechanism in groove at back of Jig (3).
- Press Mechanism into Barrel until back of Mechanism is flush with back of Jig (4).

