

Phone: (888) PEN-KITS

(736-5487)

www.WoodTurningz.com

# GROOVY TWIST PEN KIT

Instructions


#### **Kit Features**

- · Smooth twist mechanism
- Parker<sup>™</sup> style refills (RE-PARK)
- Overall length: 5-1/2"

## Required Accessories & Materials

- 7mm mandrel
- 2-pc. Race Car bushing set (PKRACEBU)
- Drill bit 3/8" (DB3/8)
- Universal trimming kit (BTRIMKIT8)
- Glue (We recommend the thick "gel" CA glue—GTHICK2)
- · Sanding and finishing supplies

# Diagram A - Parts and Assembly



#### **BLANK PREPARATION**

The Groovy pen has a single tube measuring 2-31/32". **Cut** your blank approximately 1/16" longer than the tube to allow for squaring with the barrel trimmer. Use a medium drill speed to **drill** the blank. Raise the bit from the blank every 1/4" to 1/2" to allow the chips to clear from the flutes of the drill bit. Don't force the drill bit; use an even pressure and let the bit do the work. After drilling the blank, **sand** the exterior of the brass tube to roughen its surface and use CA **glue** to glue the tube inside the blank. Sand or barrel trim to **square** the ends of the blank.

#### **TURNING THE PEN**

**Set up** the mandrel as shown in Diagram C. The Groovy pen's upper and lower bushings both have an outside diameter of .475" (see Diagram B). **Turn** the pen blank to the bushing diameter at the ends. **Sand** with abrasives and **finish** with your choice of polish.

#### **ASSEMBLY**

(Line up finished parts according to Diagram A)

To avoid damage to components when assembling, use a vise with covered jaws or one of WoodTurningz' pen presses.

- 1. Press the Tip into either end of the barrel.
- 2. Drop Clip Holder through hole in Clip.
- 3. Insert and press the Clip Assembly into the opposite end of the
- 4. Drop the Refill with the Spring into the opening at the Clip end.
- 5. Screw the Twist Mechanism into the Clip Assembly Threads.
- 6. Mount and push the twist Cap over the mechanism stem.
- 7. The pen is now ready to operate by twisting the Cap in either direction to advance or retract the Refill.

### Diagram B - Bushings

