


Phone: (888) PEN-KITS





CLOCK INSERT

Instructions

CLOCK INSERT

Mini-Clock Insert: This insert is 1 7/16" overall diameter. It fits in a 1 3/8" hole with

1/4" mounting depth.

50mm/2" Insert: This insert is 2" overall diameter. It fits in a 1.7" hole with

1/4" mounting depth.

70mm/2.75" Insert: This insert is 2.75" overall diameter. It fits in a 2.25" hole with

11/16" mounting depth. AAA Battery not included.

90mm/3.54" Insert: This insert is 3.54" overall diameter. It fits in a 3-5/16" hole with

5/8" mounting depth. AA Battery not included.

SETTING THE CLOCK

To set the clock, remove the plastic stopper. Pull the tiny stem out from the side and turn the hands until they reach the specified time. Push the stem back to its original position. *Note: remove the clear protective coating on face of the clock insert.

REPLACING THE BATTERY

To change the battery, use a small tool to pry the backing off. You will then see the battery for easy change.